

# **I N S T R U C T I O N S**

# **F O R   U S E**

**- Original -**

**Vehicle type:** Roll trailer 30' 160t  
9,2 x 3,2 x 0,95/1,0m

**Serial number:** 80082-3 / 1-6

**Year of manufacture:** 08/2015

**Customer:** Grimaldi  
Italy

**Manufacturer:** Seacom International AG  
Berbiceweg 5  
CH - 8212 Neuhausen

**Tel.** ++41 (0) 52 632 04 00  
**Fax** ++41 (0) 52 632 04 09

---

## Table of Contents

1.	General Information.....	Page 4
2.	Safety Instructions.....	Page 6
3.	Specifications.....	Page 8
4.	Operating Instructions.....	Page 9
5.	Maintenance Instructions.....	Page 13
6.	Spare Parts.....	Page 17

## 1 GENERAL INFORMATION



**Please carefully read these instructions for use before taking the roll trailer into operation!**

**Observe the safety instructions!**

**Keep these instructions for use for future reference!**

### 1.1 Introduction

Read the following operating and maintenance instructions carefully before taking the roll trailer into operation.

These instructions must be available to every person, operating the roll trailer or carrying out maintenance or repair works on the roll trailer.

The roll trailer shall only be employed, operated and maintained according to the information given in these instructions for use.

### 1.2 Durability

SEACOM roll trailers are robust and require only little maintenance. Please make sure that any damage is instantly remedied by qualified specialists in order to avoid failure of the roll trailer.

To ensure that the roll trailer can be operated safely, use only OEM-quality components.

### 1.3 Intended Use

SEACOM roll trailers are vehicles to transport cargo on companies' premises, NOT on public roads. To use the roll trailer for any other purpose is beyond the intended scope of application and can result in damage to people or to the roll trailer.

### 1.4 Warranty

Failure to comply with these instructions for use shall invalidate the warranty.

This is particularly true for any damage caused by the following actions:

- If you use the roll trailer for any other purpose than its intended use.
- If you overload the roll trailer.
- If you or a third party carry out any alterations on the roll trailer without prior permission of SEACOM International AG.
- If you fail to carry out the necessary tests and maintenance works or if you do not carry them out on schedule.

---

## 1.5 Contact details

Seacom International AG  
Berbiceweg 5  
CH - 8212 Neuhausen

Telefon        ++41 (0) 52 632 04 00

Telefax       ++41 (0) 52 632 04 09

## 2 SAFETY INSTRUCTIONS

### 2.1 General information

Always adhere to the current national safety regulations of the country in which the roll trailer is operated.



Make sure that the roll trailer is operated, maintained and repaired only by authorized and sufficiently trained and qualified personnel.

Check the roll trailer for any defects or faults before and while using it.

Stop the operation instantly when you notice defects or faults.

### 2.2 Loading the roll trailer

Never exceed the maximum capacity of the roll trailer indicated on the data plate!



Make sure that the cargo is spread uniformly over the complete load area.

Avoid concentrated loads on the load area, especially when the cargo is heavy.

Fix the load on the roll trailer securely. It shall be prevented from slipping or falling down.

Make sure that the load is not bigger than the dimensions of the platform.

### 2.3 Operating the roll trailer

Make sure that the towing vehicle has an appropriate capacity.



Never exceed the maximum speed indicated in these instructions for use.

Never operate the roll trailer with people sitting or standing on the roll trailer.

Make sure that at no time people stand or walk underneath the gooseneck.

The roll trailer shall be operated only on even and solid ground.

The speed shall be adapted to the traffic, surface and weather conditions.

Be very careful when driving on ramps.



Reduce speed in curves.

Make sure that nobody is standing or walking in the danger area of the roll trailer while it is in operation or during the process of coupling or uncoupling.

## 2.4 Parking the roll trailer

Always prevent the roll trailer from rolling when it is parked.



## 2.5 Maintenance works on the roll trailer



Make sure that the roll trailer is in a safe parking position and prevented from rolling before carrying out maintenance works on the roll trailer.

Repair and maintenance works must only be carried out by trained and qualified specialists.

### 3 SPECIFICATIONS

<b>Weights and loads</b>		
Capacity	160.000 kg	
Tare weight	13.900 kg	
Axle load	4x 36.100 kg	
5th wheel load (without gooseneck)	29.500 kg	
<b>Dimensions</b>		
Platform length	9.200 mm	
Platform width	3.200 mm	
Platform height	950 / 1000 mm	front / rear
Platform cover	5/7 mm	tear plate
Rear overhang	3.200 mm	
<b>Running gear</b>		
Number of axle lines	2	
Number of wheels	8	
Tyre size	840x500x1312	solid rubber
<b>Speed</b>		
Speed max.	6 km/h	with load
	16 km/h	without load
<b>Accessories</b>		
D-Rings	26 (4+9+9+4)	MBL 36t
Hook type coupling at front	Above gooseneck tunnel	With eye-lets for safety-chains
C-type fork pockets		
<b>Paint finish</b>		
Colour	RAL 3011	Brown red

Deviations in weights and dimensions reserved.



---

## 4 OPERATING INSTRUCTIONS

### 4.1 Application

- The roll trailer should only be used for internal transports of any kind of general cargo in accordance with the operating guidelines.
- The transport of persons is not allowed.
- Every day before the start of operation the driver of the towing vehicle has to check the roll trailer for visible defects.
- During operation the driver has to observe whether any defects or faults occur.


### 4.2 Loading the roll trailer

- Make sure that the roll trailer is parked on horizontal ground.
- The weight of the cargo put on the roll trailer shall not exceed the maximum capacity.
- The cargo that is to be transported shall be fixed and secured adequately.
- Always make sure to prevent the cargo from falling off the roll trailer and from sliding.

## Loading Diagram

- To avoid overloading, always ensure that the centre of gravity is within the respective areas in the diagram (see loading scheme).

### Rolltrailer 30 feet, 160 tons, 3.2m wide



## **4.3 Coupling the roll trailer to the gooseneck**


- Drive backwards with the towing vehicle and the gooseneck.
- Place the tongue of the gooseneck exactly into the mouth of the roll trailer.
- Lift the gooseneck with engaged reverse gear and unbraked towing vehicle
- Make sure that the gooseneck is hooked into the roll trailer correctly and the safety chains are connected to the roll trailer properly.
- Lift the roll trailer via the lifting hydraulics of the towing vehicle until the front wall of the roll trailer is approximately 100 – 150 mm over the ground.

## **4.4 Driving the towing vehicle with roll trailer**


- The roll trailer shall only be towed by an appropriate towing vehicle with a lifting capacity of at least 35 t and a lifting height of at least 1000 mm in combination with an adequate gooseneck.
- The roads shall be even, horizontal and free from obstacles.
- The permitted speed and the current safety regulations shall in any case be complied with.
- The maximum speed under load is 6 km/h.
- In curves the speed has to be reduced.
- When reversing and the rear view is insufficient or obstructed, the driver has to be supported by another person, indicating the direction.

#### 4.5 Driving over ramps

- When reversing towards an upgoing ramp as shown in below sketch, driver must lower the fifth wheel to maintain a ground clearance under the trailer front leg of 3-5 cm in order to achieve a maximum clearance rear.



- When the trailer wheels have passed the upper end of the ramp, driver must lift the fifth wheel to maximum height to achieve a sufficient ground clearance under longitudinal beams of the trailer (see sketch below).



## 5 MAINTENANCE INSTRUCTIONS

### 5.1 General information

The following tests and maintenance works have to be carried out at regular intervals to ensure that your roll trailer is working reliably and securely. Defective parts have to be exchanged instantly. As spare parts you should use only OEM-quality components, which fulfil the specified requirements and correspond to the national safety regulations of your country.

### 5.2 First inspection

Wheel bearings have to be checked and if necessary readjusted after the first 10 operating hours

#### How to readjust wheel bearings?

- Make sure that the roll trailer is in parking position.
- Lift the rear side of trailer so that the wheels can be rotated by hand.
- Put suitable supports under the lifted trailer.
- Check wheels: In case there is axial movement or the rotation is not smooth,
  - remove the hub cap (warm the cap up to app. 60°C).
  - remove the split pin from the horned nut.
  - tighten the horned nut until the wheel is blocked.
  - untighten the horned nut until the wheel rotates freely but so that there isn't any axial movement.
  - refit the split pin.
  - refit the hub cap (warm the cap up to app. 60°C).
- Make sure that you did not forget to refit any parts.
- Lower rear side of trailer.

### 5.3 Running gear

Carry out visual inspections of the running gears at regular intervals of approximately 6 months.

### 5.4 Tyres

Carry out visual inspections of the tyres every month.

## 5.5 Wheels

Inspect wheels at regular intervals of approximately 6 months:

1. Check how the wheel is rotating.
2. Check the sound. If the wheel is making any abnormal sounds, demount the wheel and check the roller bearing. Replace it if necessary.
3. Check the axial movement of the wheel. If you notice any axial movement readjust the roller bearings (see above "How to readjust wheel bearings?")

In case of heavy or frequently use, please shorten the interval of inspection.

## 5.6 Frame

Carry out visual inspections of the frame and the welding joints at regular intervals. The frame is made of structural steel. In case of damage it can be repaired by qualified staff. For questions, please contact the manufacturer.

## 5.7 Lubrication

Greasing point	Number	Greasing interval
Axle pivot pins	4	1 month
Rocker beam pins	2	1 month
Wheel set (wheel bearings)	8	6 months

**N.B.: The intervals at which greasing is necessary depend on the operating conditions of the roll trailer. In case of heavy use, please shorten the greasing intervals.**

**Lubricant:** Standard multi purpose grease  
**Viscosity class NLGI 2.**

## 5.8 Tightening torque for screws and nuts

All screws and nuts have to be checked and tightened respectively on time a month

Friction value:  $\mu_{\text{tot.}} = 0,12$  for screws and nuts without after-treatment as well as phosphated screws.  
If not otherwise indicated the  
tightening torque can be taken  
from the following table:

**Metric standard threads (ISO) DIN 13, sheet 13**

Dimension	8.8		10.9		12.9
M4	2,8		4,1		4,8
M5	5,5		8,1		9,5
M6	9,5		14		16,5
M7	15		23		28
M8	23		34		40
M10	46		68		79
M12	79		115		135
M14	125		185		215
M16	195		280		330
M18	280		390		460
M20	390		560		650
M22	530		750		880
M24	670		960		1100
M27	1000		1400		1650
M30	1350		1900		2250
M33	1850		2600		3000
M36	2350		3300		3900
M39	3000		4300		5100

## Maintenance Records

Serial number: \_\_\_\_\_

Date of commissioning: \_\_\_\_\_

Date of first inspection: \_\_\_\_\_

Carried out by: \_\_\_\_\_

### Periodic inspections / maintenance works



Date	Result	Defects remedied on                      by		Signature




## 6 SPARE PARTS

### 6.1 GENERAL VIEW


Dwg. No. 80082-3		
Item	Description	Part. No
6	Axle guard 50x12	80082-3-6
31	Tear plate 5/7 mm	80082-3-31
39	D-Ring	80082-3-39
41	Screw M20x60 DIN933	80082-3-41
42	Washer M20 DIN 127A	80082-3-42
43	Wheel set 840x500x1312	80082-3-43 → 6.2
44	Rocker beam L01250	80082-3-44 → 6.3





## 6.2 WHEEL SET 840X500X1312

Dwg. No. 80082-3-43		
Item	Description	Part. No
1	Wheel 840x500	80082-3-43-1
2	Wheel body	80082-3.43-2
3	Hub cap d=237	80082-3.43-3
4	Washer	80082-3.43-4
5	Castle Nut M100x2	80082-3.43-5
7	Split pin 12x150 DIN94	80082-3-43-7
8	Taper roller bearing 32228	80082-3-43-8
9	Screw 8x35 DIN912	80082-3-43-9
10	Washer M8 DIN127	80082-3-43-10
11	Bush 100x105x60	80082-3-43-11
12	Distance tube	80082-3-43-12
13	Axle	80082-3-43-13
14	Washer	80082-3-43-14
15	Fey-ring seal FK6 170 ASKD 250	80082-3-43-15
17	Lubrication nipple AM10x1 DIN71412	80082-3-43-16



### 6.3 ROCKER BEAM

Dwg. No. 80082-3-44		
Item	Description	Part. No
9	Bush 115x110x60	80082-3-44-9
10	Axle guard 40x10	80082-3-44-10
11	Screw M16x50 DIN933	80082-3-44-11
12	Washer M16 DIN 127	80082-3-44-12
15	Bolt d=100	80082-3-44-15
16	Bolt d=160	80082-3-44-16
17	Lubrication nipple AM10x1 DIN71412	80082-3-44-17

