







Point loads on the platform to be placed or transferred using transversal supports to the longitudinal beams




Loading instruction

- 1) Identify loads center of gravity
- 2) Calculate the loads, coming to the Rolltrailer platform acc to below scheme



Load center of gravity must be within the areas, corresponding to the load



This drawing is the property of Transport Systems Seacom AG (TSS) / Seacom Trailer Systems GmbH (STS). No part of this drawing may be reproduced, transmitted or stored electronically nor may be it rented to any third party without the written consent of TSS / STS (in accordance with §1 & §11 in German law dated 19.July 1981).				universal tolerances		Load diagram	
				DIN ISO 2768-1 m		1:	
				DIN ISO 2768-2 L		1:	
				DIN 2310-11 II B			
				2019		date	
				drawn		M.R	
				checked			
				Norm			